



NOTICE

Wear gloves when handling the Touch Sensor Module.

The Touch Sensor Module is sensitive to external forces. Do not lift or apply force to the PCB connector at the end of the module, as this may cause PCB to delaminate and/or the connector to break. Be careful when connecting the sensor to an interface board.

Do not bend, do not use excessive force.

