

Getting started with zForce AIR Touch Sensor Evaluation

Plug and Play

Connect the sensor and immediately get touch input to your computer.

Explore the features of the zForce AIR Sensor

Use the Neonode software to visualize touches and play with sensor settings.

Use the zForce AIR Arduino Library

Add the zForce AIR Sensor to your Arduino project. Connect with I2C and use the provided functions for SW integration.