

# SDK Function Support Matrix

SDK		Supported by Product
Class	Function	zForce AIR™ Touch Sensor
PlatformDevice	GetFingerFrequency	X
	SetFingerFrequency	X
	GetIdleFrequency	X
	SetIdleFrequency	X
	GetMcuUniqueIdentifier	X
	SetMcuUniqueIdentifier	
SensorDevice	GetEnable	X
	SetEnable	X
	GetDisable	X
	SetDisable	X
	GetOperationModes	X
	SetOperationModes	X
	GetResolution	X
	SetResolution	
	GetTouchActiveArea	X
	SetTouchActiveArea	X
	GetReverseTouchActiveArea	X
	SetReverseTouchActiveArea	X
	GetDetectedObjectSizeRestriction	X
	SetDetectedObjectSizeRestriction	X
	GetNumberOfTrackedObjects	X
	SetNumberOfTrackedObjects	X
	GetHidDisplaySize	X
	SetHidDisplaySize	X
	GetOffset	X
	SetOffset	X
GetFlipXY	X	
SetFlipXY	X	

X = Supported

## Read More

- [SDK System Requirements](#)
- [Getting started with SDK for Linux](#)
- [Getting started with SDK for Windows](#)
- [Example Program Pseudocode](#)
- [Essential SDK API](#)
- [SDK Complete Function Library](#)
- [SDK Function Support Matrix](#)
- [Release Notes](#)

- [Legal Notice](#)